

Jr Classic Power Distribution

02/21/97

Jr Classic series

All firmware versions

+5V

C3.1	C30.1	C45.112	C46.112	C53.1	C68.1
C69.1	C72.1	C73.1	C78.1	C79.1	C80.112
C81.1	CB13.1	CB15.1	CB16.11	CB17.1	CB2.1
CB21.1	CB22.1	CB3.1	CB30.1	CB33.1	CB35.1
CB36.1	CB37.11	CB5.1	CB50.11	CB51.1	CB52.1
CB53.1	CB54.1	CB55.1	CB56.1	CB57.1	CB58.1
CB59.1	CB60.1	CB61.1	CB62.1	CB63.1	CB64.1
CB65.1	CB66.1	CB67.1	CB68.1	L1.1	LED1.2
LED2.2	LED3.2	LED4.2	LED5.2	LED6.2	PC2.11
PVR1.2	R27.1	RP1.1	RP11.1	RP12.1	RP2.1
RP5.1	RP6.16	RP7.1	RP9.11	U1.20	U1.7
U10.2	U10.8	U11.20	U14.14	U15.14	U16.16
U17.20	U2.20	U20.3	U20.4	U21.2	U21.8
U22.8	U23.20	U24.14	U25.16	U26.16	U27.20
U28.11	U29.9	U3.20	U30.201	U32.20	U33.32
U34.20	U38.24 & 12	U41.24	U42.16	U44.24	U45.20
U46.16	U47.20	U5.4	U52.7 & 12	U59.14	U6.20
U63.20	U7.16	U71.11	U71.31	U71.32	U8.20
UP1.5	UP2.11	UP2.12	UP2.13	UP2.3	UP2.4
UP2.5					

+12V

C2.17	CB19.1	CR2.1	CRP7.1	JU2.1	PC4.1
R59.1	U36.4	UP2.161			

-12V

C1.17	CR1.2	CRP8.2	PC3.1	U36.11	UP2.9
VR1.21					

-5V

C4.11	C51.12	U25.7	U26.7	VR1.3	
-------	--------	-------	-------	-------	--